

Infinix



SURF Smart 3G

User Guide / Manuel d'utilisation / دليل المستخدم

Contents

Contents	1
About Android.....	4
Applications.....	4
Getting started	5
Touch screen & keys	6
Touch tips.....	6
Zooming tips.....	6
Rotate the screen	7
Key tips	7
Home screen	8
Quick start: Home screen	8
Working with Menus	8
Shortcut	10
Widget	10
Arranging your Home screen	11
Changing the background of your Home screen	11
Application menu	12
Application menu.....	12
Phone status bar and notifications	12
Status icons	12
Checking notifications and ongoing activates.....	13
Toolkits	14
Dial pad	14
Make a call	14
Answer or reject an incoming call.....	14

Options available during a call	15
Conference Call	15
Text entry	16
On-screen keyboard	16
Enter text	17
Enter Various Characters.....	17
Edit Text.....	17
Select Text	18
Cut /Copy/Paste Text.....	18
Communication.....	19
Messages.....	19
Contacts	21
Phone.....	24
Email.....	24
Multimedia	27
Camera	27
Music	28
FM radio	31
Gallery	32
Sound recorder	34
Tools	35
Calendar.....	35
Clock.....	35
Calculator.....	36
Browser	36
Connect to Networks and Devices.....	40

Determine the Network You Are Using	40
Edit or Create New Access Points	40
WLAN Networks.....	40
Bluetooth.....	41
Connect to a computer via USB.....	42
Working with Secure Certificates	42
Install Secure Certificate from SD Card.....	43
Settings	43
Other popular features	46
Accessing Password.....	46
PIN Code	47
PIN2 Code	47
PUK Code	47
PUK2 Code.....	48
Precautions	48
Frequently Asked Questions and Troubleshooting	50
Safety Information and Notices	53
Using the Mobile Phone and Charger	53
Using the Mobile Phone	53
Using the Battery	55
Using the Charger	56
Requirements for Mobile Phone.....	57
Requirements for the Battery.....	57
Requirements for the Charger and AC Adapter	58
Cleaning and Maintenance.....	58

About Android

An Android phone can perform many of the same functions as a computer. But you can also adjust it to better suit your needs, to receive the information you want, and have fun at the same time. You can add and delete applications, or enhance them to improve functionality. At Android Market you can download a range of applications and games from a constantly growing collection. You can also integrate applications on your Android phone with your personal data and online accounts. For example, you can back up your track of your appointments, and engage in as much social networking as you like.

Applications

An application is a phone program that helps you perform a task. For example, there are applications to make calls, take photos and download more applications.

Note: The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only.

The content of the manual is correct when it is released, but we reserve the right to modify the technical specification without additional notification.

Some content in the manual may be different from the mobile phone, as the accessory software, SIM card or service varies by providers.

Getting started

let's get you up and running

Assemble & charge

SIM card in

Please according to the label on the phone. Make sure that the clipped corner of the SIM card is facing the correct direction and the metallic contacts are facing the correct direction. Slide the SIM card into the card slot until it stops.

SD card in

Slide SD card into the SD card slot with the metallic pins facing downwards. Push the card until it locks into place.

Battery in

With the metallic contacts of the battery facing the metallic contacts in the battery slot, press the battery down until it locks into place.

Charge up

Ensure the battery is inserted in the handset. To charge the battery, plug in the charger connector at your phone (USB interface) and then plug the other end into an AC power socket. The battery symbol indicates the charging status. While charging, the charge indicators will scroll. When all the scroll bars are steady, the battery is fully charged. Disconnect the charger from the phone. Disconnect the charger from the AC power socket.



Note: If the battery is powerless, the battery icon will reappear after a few minutes of charging.

Touch screen & keys

a few essentials

Touch tips

Here are some tips on how to navigate around your phone.

Touch

To choose an icon or option, touch it.

Touch & hold

To open special functions or additional options. Try it: From **Application menu**, touch **Music** icon to enter Music library, then touch and hold an artist, a song, or an album, some options will be available to you. For example: play, add to playlist, delete, etc.

Drag

To scroll through a list or move slowly, drag across the touchscreen. Try it: on the Home screen, touch **Contacts** icon to enter contacts list, you can drag contacts list up or down to scroll list.

Slide

To slide by moving your finger left or right on the touch screen quickly. Scroll through a list or move quickly, slide across the touchscreen (drag quickly and release).

Double-touch

Touch quickly twice to zoom in/out. For example, double-touch a picture in Gallery to zoom in/out.

Zooming tips

When looking at maps, webpages or photos, place two fingers on the touch screen at once and pinch them together to zoom out or spread them apart to zoom in.



Note: Use the zoom function when you view photos, maps or when you browsing the web.

Rotate the screen

On some screens, the orientation of the screen rotates with the phone as you turn it from upright to its slide and back again. You can turn this feature on and off.

Key tips

Power/Lock key

- When powering off status, press and hold to turn on the phone;
- When powering on status, press and hold to enter phone options (Power off, Reboot, Airplane mode, and so on);
- To save your battery, prevent accidental touches or when you want to wipe smudges off your touch screen, put the touch screen to sleep by pressing Power/Lock key;
- To wake up the touch screen, just press Power/Lock key again, and then drag the lock icon to the right on the screen to unlock according to the indication on the screen.

Menu key

- Opens a menu with items related to the current screen/application.

Home key

- Press Home key to close any menu or app and return to the Home screen. If you are viewing the left or right Extended Home screen, open the central Home screen.
- Press and hold Home key to view the applications you have used recently.

Back key

- Press Back key to return to the previous screen you were working on.

Volume keys


Press Volume keys to change the volume. When playing music or video files, press Volume keys to adjust media volume.

Home screen

quick access to the things you need most

Quick start: Home screen

The Home screen gives you all your latest information in one place. It's what you see when you turn on the phone. It is the equivalent of the desktop on a computer. It's your gateway to the main features in your phone. You can customize your Home screen with shortcuts, widgets, folders, and wallpapers.



You need slide the Home screen left or right to view more content in other panels on the Home screen. You can add shortcuts, widgets, folders, etc. to Home screen.




Note: Your Home screen might look a little different.

Working with Menus

The phone provides you with Options menus and context menus.

Options menus



- Options menus contain tools that apply to the activities of the current screen or application, not to any specific item on the screen. You can open options menu by pressing **Menu key**.
- Not all screens have options menus. If you press **Menu key** on a screen that has no options menu, nothing happens.



Options menu contain items that apply to the current screen or to the application as a whole.

Context menus

Context menus contain tools that apply to specific item on the screen. You can open a context menu by touching and holding an item on the screen. Not all items have context menus. If you touch and hold an item that has no context menu, nothing happens.



Shortcut

To add a shortcut to Home screen

1. From Home screen, touch **Launcher** icon.
2. From **APPS** tab, you will see application menu.
3. Touch and hold an application icon until it vibrates, then back to the Home screen, and drag it to the desired location.

To remove a shortcut on Home screen

If you want to remove the shortcut, you can touch and hold the shortcut icon on Home screen until it vibrates, and then drag it to remove tab.

Widget

A widget is small application on the Home screen that typically displays information such as Analog clock, Music and you can use directly on your Home screen. For example, the Music widget allows you to start playing audio files directly on Home screen. You can also add a widget such as Analog clock that shows time.

You can also download additional widgets from the library of Android widgets.

To add a widget to Home screen

1. From Home screen, touch **Launcher** icon.
2. Touch **WIDGETS** tab, you will see widget options menu.
3. Touch and hold a widget icon to pick up the widget, then back to the Home screen, and drag it to the desired location.

To remove a widget on Home screen

If you want to remove the widget, you can touch and hold the widget icon on Home screen until it vibrates, and then drag it to remove tab.

Arranging your Home screen

To move an item on Home screen

Touch and hold an item on Home screen until it vibrates, then drag it where you want.

To organize your apps with folders

To make a new folder on your Home screen, stack one app on top of another.

To name folder on Home screen

1. Touch the apps stack on Home screen to open
2. Touch the **Unnamed Folder** to show the name folder field.
3. Edit the folder name.

To move application shortcuts on Home screen to a folder

Touch and hold the item on Home screen until it vibrates, and then stack the app on top of others.

To move application shortcuts in a folder to Home screen

Touch and hold the item in a folder until it vibrates, and then drag the item out of the folder.

Changing the background of your Home screen

Adapt the Home screen to your own style using wallpapers from Gallery, Live wallpapers, Video wallpaper or Wallpapers.

Touch and hold the Home screen to select Wallpapers, and select wallpaper from Gallery, Live wallpapers, Video wallpaper or Wallpapers. Then set it as wallpaper.



Tip: You can use camera to take a photo, and then set it as wallpaper.

Application menu

enjoy applications from the Application menu

Application menu

The Application menu, which you open from your Home screen, contains the applications that come installed with your phone. The Application menu extends beyond the screen width, so you need to slide left and right to view all content.

To open the Application menu

1. On Home screen, touch **Launcher** icon.
2. Touch **APPS** tab.

To browse the Application menu

Open the Application menu, then slide the screen right or left.

Phone status bar and notifications

The status bar at the top of the screen contains icons that tell you about messages and phone status and shows what's going on in your phone. At the top you get notifications when there is something new or ongoing. For example, new message, missed call, signal strength, battery status and other information appear here.


Status icons

The following status icons may appear on your screen:

Icon	Statement	Icon	Statement
	SIM Network signal level		Headset is inserted

	Indicates battery capacity		Bluetooth
	Unread messages		WLAN is connected
	Missed calls		Airplane mode is activated
	Alarm is activated		USB is connected
	Vibrate		Silent

Checking notifications and ongoing activates



You can drag down the status bar to open the notification panel and get more information. For example, view missed calls from notification panel. You can also open running applications, such as the music player.

To open the Notification panel

Drag the status bar downwards.

To close the Notification panel

Drag the tab at the bottom of the notification panel upwards.


To open a running application

from the notification panel

From the notification panel, touch the icon for the running application to open it.

Toolkits

In the toolkits you can quickly start the common applications such as Bluetooth, WLAN and so on. Open the Notifications panel by dragging down the top of screen with your finger.



Toolkits


Dial pad

Make a call


Touch **Phone** icon on the Home screen.

In dialing screen, input number and touch **Dial** icon to dial the inputted number.


Dial pad



Incoming call screen



During a call



Answer or reject an incoming call

To answer an incoming call

To answer an incoming call, drag  towards the right side according to the indicate on the screen.

To reject an incoming call

If you want to reject, slide  towards the left side according to the indicate on the screen.

Options available during a call

During a call, there are some call options available to you. These call options can be seen only during a call. When a call is in progress, you can put it on hold, initiate a phone conference, mute your microphone etc.

To	
Key pad: Go to the key pad .	Touch 
Speaker: To turn on/off the speaker.	Touch 
Mute: Mute your voice so that the other party cannot hear you.	Touch 
Hold: To place a call on hold.	Touch 
Add call: Open dial pad to dial the second call.	Touch 
End: To end a call.	Touch 

Press **Volume keys** to adjust the call volume.


Conference Call

If you accept a new call when you are already on a call, you can switch between the two callers or merge the two calls into a conference call.

1. Make a call to the first participant

2. When you are connected, touch  to dial the second caller.
3. When you are connected, the first participant is put on hold, touch **Merge** icon. The participant is added to the conference call.

You can add as many callers as your carrier supports.



Touch to swap calls

Touch to merge the calls into a conference call


Recommendation: Contact your service provider to know whether they support conference calls and how many participants you can include.

Text entry

On-screen keyboard

Touch the keys of the on-screen QWERTY keyboard to enter text conveniently. You can open this keyboard by touching a text field.

Android Keyboard input method



Touch this icon to select desired contact from phonebook.

Text field

Send message

Touch to capitalize the next letter you type.

Enter text

- Touch the keys on the keyboard to type.
- Use the **Delete key**  to erase characters to the left of the cursor.
- When you finished typing, Press **Back key** to close the keyboard.

Enter Various Characters

- Touch the **Symbols key**  to switch to the numbers and symbols keyboard.
- Touch  on the symbols keyboard to view additional symbols.

Edit Text

You can edit the text you enter in text fields and use menu commands to cut, copy, and paste text, within or across applications. Some applications do not support editing some or all of the text they display. Others may offer their own way to

select text you want to work with.

- Touch and hold the text field that contains the text to select the word.


- Cut or copy the text.

Select Text

You can select text for cutting or copying. The selected text is highlighted in blue.

- Touch and hold the portion that contains text. Some options open with icons.

- Move the cursor to select the text.



Cut /Copy/Paste Text

1. Touch **Cut** icon or **Copy** icon in the menu that opens.
2. Touch and hold the text field where you want to paste the text.
3. Touch **PASTE** in the menu that opens. The text is inserted at the cursor.

You can paste the text that you copied from one application into a text field in any application.

Communication

it's good to talk, text or email. . .

Messages

Find it: Application menu > Messages

You can compose, send and receive text messages from your phone, and also can compose, send and receive multimedia messages, which contain media files such as pictures, videos and audios.

When you view your messages, they appear as conversations, which means that all messages to and from a particular person are grouped together.

● **Compose new message** 错误!未找到引用源。

1. From your Home screen, touch **Messages** icon or find it: **Application menu > Messages.**

2. Touch .

3. To add recipient(s), touch , then find and mark the contact name. To add more than one contact, mark the contact name for the desired recipients. You can also enter the recipient's phone number manually.

4. After you finish marking contact(s), touch .

5. Touch **Type message** to enter your message text.

6. If you want to insert a media file, touch , and select an attachment.

7. Send the message and select SIM.

When editing message, press **Menu key** 错误!未找到引用源。 , some additional options will be available to you. For example,

add subject, and insert smiley. You can touch the options to do actions.



● Delete message threads

1. From your Home screen, touch **Messages** icon or find it: Application menu > Messages.
 2. Touch and hold the message thread.
 3. Select the conversations you want to delete.
 4. Touch **Delete**, then touch **Delete** in the menu that pops up.
- You can also press **Menu key** and touch **Delete all threads** to delete all message threads from the window.

● Forward a message

1. From your Home screen, touch **Messages** icon or find it: Application menu > Messages.
2. Touch the conversation containing the message you want to forward.
3. Touch and hold the message you want to forward.

4. Touch **Forward** in the menu that opens.
5. Add recipient(s), touch , and then find and mark the contact name. To add more than one contact, mark the contact name for the desired recipients. You can also enter the recipient's phone number manually.
6. Select SIM, to send the message.

● **Lock a message**

You can lock a message.

1. From your Home screen, touch **Messages** icon or find it: Application menu > Messages.
2. Touch the conversation containing the message you want to lock.
3. Touch and hold the message you want to lock.
4. Touch **Lock** in the menu that opens. A lock icon appears. Unlock a message by touching and holding the message and then touch **Unlock**.

● **Messages settings**


1. From your Home screen, touch **Messages** icon or find it: Application menu > Messages.
2. Press **Menu key**, select **Settings** in the menu that opens.
3. You can change messages settings, such as delete old messages as limits are reached, request a delivery report for each message you send.

Contacts

Find it: Application menu > Contacts

The Contacts application offers you to store and manage all your contacts.

● **Contacts screen overview**



● **Add a contact**

1. From your Home screen, touch **Contacts** icon or find it: Application menu > Contacts.
2. Touch .
3. Select storage path to which you want to add this new contact, or add new account.
4. Enter the information for the contact.
5. After you finish, touch **DONE**.

● **Search a contact**

1. From your Home screen, touch **Contacts** icon or find it: Application menu > Contacts.
2. Touch .
3. Input the first character of the name you are searching for in the cursor, and then all records meeting the conditions will be displayed. Search results will be different due to different input content.

● Additional options

From contacts list screen, press **Menu key** 错误!未找到引用源。 , some additional options will be available to you. For example, import/export, and share visible contacts and so on.

•**Delete contact:** You can mark much more than one contact, and then delete these marked contacts.

•**Contacts to display:** To select which contacts to display in the contacts list.

•**Import/export:** Copy contacts to which you want import.

•**Accounts:** You can synchronize your phone contacts with a synchronization account.

•**Share visible contacts:** You can share contacts via Bluetooth, Email, and so on.

● Contact groups

You can assign contacts to groups to get quicker access to them from the Contacts application. It allows you to create a new group such as VIP, schoolmate, friends, family or co-worker.

To create a new group

1. From your Home screen, touch **Contacts** icon or find it: **Application menu > Contacts**.
2. Touch **Groups** tab.
3. Touch .
4. Input the information of group, then touch **DONE**.

To assign a contact to a group

1. From your Home screen, touch **Contacts** icon or find it: **Application menu > Contacts**.
2. Touch **Groups** tab.
3. Touch a group to which you want to assign contacts.
4. Press **Menu key**, touch **Edit** in the menu that opens.
5. Touch **Type person's name** to input the contact's name, then the corresponding contact entry will pop up, select the desired contact entry.

6. After you finish editing, touch **DONE**.

● Favorites

You can set contacts as favorites so that you can get access to them from the Contacts application. Only the contacts stored in phone memory can be set as favorites.

To set a contact as favorite

1. From your Home screen, touch **Contacts** icon or find it: Application menu > Contacts.
2. From contacts list, touch a contact which you want to set as favorite.
3. Touch . If you want to cancel the favorite, touch .

Phone

Find it: Application menu > Phone

● Call log

Find it: Application menu > Phone > Call log tab

Touch different tabs such as All, Received, Dialed, and Missed calls on upside screen of Call log interface, and then you can view different call logs.

To	
All calls	Touch 
Received calls	Touch 
Dialed calls	Touch 
Missed calls	Touch 

Email

Find it: Application menu > Email

The Email application in your phone offers you to compose, send and receive emails through your regular email account.

You need create account first, and then create email to send. You can configure Email for most accounts in just a few steps.

● **Set up an email account in your phone**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. Enter your email address and password, then touch Next.
3. If the settings for the email account cannot be downloaded automatically, complete the setup manually. If necessary, contact your email service provider for detailed settings.
4. When you are prompted, enter a name for your email account, so that it is easily identifiable. The same name shows in the emails you send from this account.
5. After you finish, touch **Next**.

● **Create and send an email**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. Touch .
3. Enter recipients' addresses, and subject.
4. Compose email. Press **Menu key**, you can attach a file, select the type of attachment, and select the file which you want to attach from the list that appears.
5. If you want to add Cc/Bcc, press **Menu key**, then touch **Add Cc/Bcc**.
6. When you finish, touch  to send the email.

● **Receive emails**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. Touch  to refresh, you can download new emails.

● **Read your emails**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. In the email inbox, scroll up or down, and touch the email you want to read.

● **Reply to an email**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. In the email inbox, scroll up or down, and touch the email to which you want to reply.
3. Touch , or touch  to select **Reply all**.
4. Enter your reply, touch  to send the email.

● **Forward an email**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. In the email inbox, scroll up or down, and touch the email you want to forward.
3. Touch  to select **Forward**.
4. Enter recipients' addresses.
5. Touch  to send the email.

● **View all folders**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Email.
2. Touch  at the top of the screen, then select **Show all folders**. You can also touch  at the bottom of the email inbox.

Multimedia


listen it, watch it, capture it, enjoy it!

Camera

Find it: Application menu > Camera

Take a photo or record a video with the camera in your phone. You can hold the camera horizontally or vertically. Share a photo or a video with your friends, or upload your photos and videos to a web service.

● **Camera control overview**



- 1 Preview your pictures or videos you captured
- 2 Take photos or record videos
- 3 Capture mode
- 4 Switch to camera mode, camcorder mode, panorama mode or multi-view mode
- 5 Switch between front camera and back camera
- 6 Settings
- 7 Zoom in or out

● **Take a photo**

- Adjust your picture size, sharpness, color effect, and other settings if you wish.
- Frame your subject on screen. You can zoom in or out by touching the Zoom icon.
- Touch the shutter icon on the screen.

The picture you just took is displayed for a moment, and then is displayed as a thumbnail.

● **Shoot a video**

- Switch to the camcorder mode
- Adjust the video quality, sharpness, and other settings if you wish.
- Point the lens to the scene you want to shoot
- Touch the start icon.
- Touch the stop icon to stop shooting.


Music

Find it: Application menu > Music

The phone comes with a Music player that plays songs, listen to audio book and podcasts you have stored. It gives you a host of setting options to make your listening experience interesting. You can easily transfer your favorite music from your PC to the SD card and experience a whole world of interesting and melodious music.

When you copy music to your SD card, the Music player searches the card for music files and builds a catalog of your music, based on information about each file that is stored in the file itself.

● **Music library**




Categories

Touch to select Artists, Albums, Songs or Playlists


The Music library offers the following multiple categories that you can select.

Categories	
Artists:	Songs classified by singers
Albums:	Songs classified by albums
Songs:	Display all songs
Playlists:	Display playlists

If you touch and hold an artist, a song, or an album, some options will be available to you. For example: play, add to playlist, delete, etc.



• Music player



You can return to the main library screen from music player screen in the Music applications by pressing **Menu key** and touch Library.

Music and settings controls


Play/Pause	Touch 
Previous/Next	Touch 
Rewind/Forward	Touch and hold 
Volume adjust	Press Volume keys
Now playing	Touch 
Shuffle	Touch 
Repeat: Touch to repeat all songs; touch again to repeat current song.	Touch 

Press **Menu key**, some additional options such as Library, Party shuffle and Add to playlist will be available to you.

FM radio

Find it: Application menu > FM radio

The phone comes with an in-built FM Radio错误!未找到引用源。 . You can listen to FM radio stations, and add them to channel list. You have to plug in an earphone, as the antenna of the FM radio. You can listen to the radio either through an earphone, or through the speaker in the phone.




- | | |
|---|---|
| 1 | Switch between earphone mode and speaker mode |
| 2 | Channel list |
| 3 | Radio on/off button |
| 4 | To fine-tune the FM frequency |
| 5 | To search for the next effective frequency |

Gallery

Find it: Application menu > Gallery

The Gallery offers you to view photos and play videos which are downloaded as well as those taken by the phone camera. From Gallery, you can also share your photos and videos with your friends, via messages, Bluetooth, or email, etc.



1. Touch an album to open it and view its contents.
2. Touch a picture or a video in an album to view it.

To

Slide show

Touch 

Share via various ways

Touch 

Delete

Touch 

When viewing a picture, press **Menu key**, some additional options will be available to you, such as slide show, edit, print, rotate left, rotate right, crop, set picture as, and details.

● Share an Album

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Gallery.
2. Press **Menu key**, touch **Select album** in the menu that opens.
3. Select the albums you want to share.


4. Touch .

5. In the menu that opens, touch the application to use to share the selected albums. You can share via email, Picasa, Messages, Bluetooth, Gmail, Google+.

Sound recorder

Find it: Application menu > Sound recorder

Record sound and play sound file.



- | | |
|---|-------------------------------|
| 1 | To start recording |
| 2 | Recording files list |
| 3 | To pause recording |
| 4 | To stop recording |
| 5 | Review and play recorded file |

Press **Menu key**, you can select recording format.

Tools


stay on top of things

Calendar

Find it: Application menu > Calendar

Your phone has a calendar for managing your time schedule. You can use the calendar to keep track of important events. After entering the calendar function menu, you can select year, month and date.

● **To set the calendar view**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Calendar.
2. Touch .
3. Select day, week, month or agenda in the menu that opens.

● **To add a calendar event**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Calendar.
2. Touch **Menu key**, then touch **New event** in the menu that opens.
3. Enter the name, location, time, and description for the event.
4. Select a reminder for the event.
5. After you finish, touch **DONE**.

Clock

Find it: Application menu > Clock

The clock allows you to view time and date.

You can also add an alarm, set the alarm and turn it on. Then, the alarm can ring at a specific time you set.

● **Add an alarm**

1. From your Home screen, touch **Launcher** icon, then find it: Application menu > Clock.
2. Touch **Set alarm**.

3. Touch **Add alarm**.
4. You need set time, ringtone, repeat, vibrate, etc. Then, turn it on.
5. After you finish setting, touch **OK**. Then the alarm can ring at a specific time you set.

Calculator

Find it: Application menu > Calculator

Keep your calculations on your finger tips with the calculator. Using this application allows you to make calculations. The calculator provides the basic arithmetic functions; addition, subtraction, multiplication, and division. You can also use an advanced panel.

● How to use the calculator

1. From your Home screen, touch **Launcher** icon or find it: Application menu > Calculator.
2. Enter the first number using the numeric keys.
3. Enter the operation for your calculation by touching the **Plus, Minus, Multiplication, or Division** key.
4. Enter the next number.
5. To view the result, touch the “=” (**equals**) key.

Press **Menu key**, you can open advanced panel to do calculation.

Touch , you can only erase one numeric before the cursor.

Touch and hold , you can erase all numeric before the cursor.

Browser

Find it: Application menu > Browser


Use your web browser to view and navigate web pages, add

pages as bookmarks, and save pages for offline reading. You can open several windows at the same time and switch among them easily. You can also request the desktop version of a web page if you don't want to view the mobile version.

● Open the web browser

From your Home screen, touch **Browser** icon or find it: Application menu > Browser.

● Search and address bar



● Manage bookmarks

Bookmarks let you access your favorite and frequently visited web pages quickly. You can add bookmarks directly from your phone browser.

To bookmark a web page

1. When you are viewing the web page, press **Menu key**.
2. Touch **Save to bookmarks**.
3. If desired, you can edit the Label.
4. When you're done, touch **OK**.

● Browser options

When you are viewing the web page, press **Menu key**, the

following options are available to you.

- **Refresh:** reloads the current page.
- **Forward:** forwards the browser to another web page.
- **Stop:** stop downloading the current web page.
- **Home:** access to the homepage.
- **Save to bookmarks:** allows you to add a URL to your bookmark list.
- **Close:** minimize or quit the browser.
- **Save for offline reading:** allows you to store the current page in memory so that it can be read later even if you loose your Internet connection.
- **Share page:** allows you to share the page via Bluetooth, Email, Gmail and so on.
- **Find on page:** allows you to search in the current page.
- **Request desktop site:** allows you to assign the browser to display the current page in the desktop view (to closely mimic the display as it would appear on a Desktop computer).
- **Bookmarks/History:** provides access to the Bookmarks screen and displays a list of the browser history you have visited.
- **Settings:** allows you to change the way you view your web pages by changing these options.

● **Change Browser settings**

You can change the browser settings and customize your browser view, such as set homepage, clear locally cached content and databases, override a website's request to control zoom behavior, choose a search engine.

The table below lists some of the more popular browser settings.

Set homepage	Set default homepage.
Clear cache	Clear locally cached content and databases.
Clear history	Clear the browser navigation history
Show security warnings	Show warning if there's a problem with a site's security.
Clear all cookie data	Clear all browser cookies.
Remember passwords	Save usernames and passwords for websites.
Clear passwords	Clear all saved passwords.
Force enable zoom	Override a website's request to control zoom behavior.
Enable JavaScript	Check to allow JavaScript to run, or uncheck to disallow JavaScript.
Reset to default	Delete all Browser data, including history, cookies, passwords, and bookmarks; restore all Browser settings to their default state.
Load images	Display images on web pages.
Quick controls	Slide thumb from the left or right edge to open quick controls and hide app and URL bars.

Connect to Networks and Devices

Your phone can connect to a variety of networks and devices, including WLAN, Bluetooth, and devices, such as headsets. You can also transfer files to/from your PC through the data cable.

Determine the Network You Are Using

1. Touch **Launcher** icon, and from Application menu, touch **Settings**.
2. Touch **More... > Mobile networks > Access point names**. The name of the wireless service provider you are currently registered with is selected in the list.

Edit or Create New Access Points

If you and your wireless service provider determine that you need to change the settings of your current access point name (APN) or to create a new one, you must obtain the APN and detailed settings from your provider.

1. Touch **Launcher** icon, and from Application menu, touch **Settings**.
2. Touch **More... > Mobile networks > Access point names**.
3. Touch an existing APN to edit it, or press **Menu key** and touch **New APN**. Enter the APN settings that you obtained from your wireless service provider.
4. When you finished, press **Menu key** and then **Save**.
5. If you created a new APN, touch it in the APNs screen to start using it.

WLAN Networks

WLAN is a wireless networking technology that can provide internet access at distance of up to 100 meters. To use WLAN on your phone, you access a wireless access point, or "hotspot".

Some hotspots are open and you can simply connect to them. Others are hidden or implement other security features, so you must configure your phone so it can connect to them.

TIP: Turn off WLAN when you are not using it, to extend the life of your battery.

● **Connect to WLAN Network**

1. Touch **Launcher** icon, and from application menu, touch **Settings**.
2. Touch **WLAN**.
3. Check WLAN to turn it on. The phone scans for available WLAN networks and displays the names of those it finds. Secured networks are indicated with a Lock icon.
4. Touch a network to connect to it

If the network is secured, you are prompted to enter a password or other credentials (Ask your network administrator for details)

● **Receive Notifications**

By default, when WLAN is on, you receive notifications in the status bar when your phone detects an open WLAN network.

1. Turn on WLAN, if it's not already on.
2. In the WLAN list screen, press **Menu key** to open Advanced options, check Network notification. You can uncheck this option to stop receiving notifications.

Bluetooth

Bluetooth is a short-range wireless communications technology that devices can use to exchange information over a distance of about 10 meters.

● **Turn Bluetooth On/Off**

1. Touch **Launcher** icon, and from application menu, touch **Settings**.
2. Touch **Bluetooth**.

3. Check or uncheck Bluetooth to turn it on or off.

Important: Go to Bluetooth and check option so that your phone can be detected by other devices.

● **Pair with Bluetooth Devices**

You must pair your phone with a device before you can connect to it. Once you pair your phone with a device, they stay paired unless you unpair them.

1. Touch **Launcher** icon, and from application menu, touch Settings.

2. Touch **Bluetooth**.

3. If Bluetooth is not turned on, check Bluetooth to turn it on. Your phone scans for and displays the IDs of all available Bluetooth devices in range.

4. If the device you want to pair with is not in the list, touch **SEARCHING**.

5. Touch the ID of the desired device in the list to pair it.

Connect to a computer via USB

You can connect your phone to a computer with a USB cable to transfer music, pictures, and other files between your phone's SD card and the computer.

You can not share your phone's data connection and SD card via USB cable at the same time. If you are using USB tethering, you must turn that off first.

The connection to USB interfaces has to be limited to USB 2.0 version or higher. The connection to so called power USB is prohibited.

Working with Secure Certificates

If your organization's VPN or WLAN Network rely on secure certificates, you must obtain the certificates and store them in your phone's secure credential storage, before you can

configure access to those VPN or WLAN networks on your phone.

If your network administrate instructs you to download the certificates from a website, you are prompted to set a password for the credential storage when you download the certificates.

Install Secure Certificate from SD Card

1. Copy the certificate from your computer to the root of the SD card.
2. Touch **Launcher** icon, and from Application menu, touch **Settings**.
3. Touch **Security**.
4. Touch **Install from SD card**.
5. Touch the file name of the certificate to install. Only the names of certificates that you have not already installed on your phone are displayed.
6. If prompted, enter the certificate's password.
7. From WLAN list, search and select the certificate.

Settings

the settings for various features of the phone

Get to know the settings in your phone so that you can personalize them to your own requirements. Go to Settings to configure how your phone looks, sounds, communication, privacy, and operations in a variety of ways:

SIM management

Set preferences on how you use SIMs inserted in your phone.

WLAN

Turn WLAN on or off, scan available WLAN networks, or add the WLAN network.

Bluetooth	Turn Bluetooth on or off, search for available Bluetooth devices, and make your phone visible or invisible to other Bluetooth devices.
Data usage	Turn the mobile data traffic on or off, and keep track of your data usage details over a specified period of time.
More...	Turn Airplane mode on or off, and configure settings for VPN and mobile networks, and enable your phone to share its mobile data connection as a portable WLAN hotspot, or through USB tethering or Bluetooth tethering.
Audio profiles	Configure how your phone rings, vibrates, or alerts you in other ways when you receive communications, etc.
Display	Let you set the screen brightness, select to switch orientation when you rotate your phone, and configure other screen settings.
Storage	Let you check out available space on your phone's internal storage, phone storage and on your SD card.
Battery	Check battery status and battery level.
Apps	Manage downloaded and running applications.
Accounts & sync	Let you add, and manage supported accounts. Enable your phone synchronize data with the synchronization accounts that you

	add.
Location services	Enable or disable Google's location service, and so on.
Security	Protect your phone by setting up different locks and passwords.
Language & input	Let you select the language for the text on your phone and for configuring the onscreen keyboard.
Backup & reset	Reset your phone.
Date & time	Let you choose preferences such as format and time zone.
Schedule power on/off	Schedule automatic powering on/off of the phone.
Accessibility	Enable your installed accessibility services and adjust related settings.
Developer options	Set options for application development. For example, you can show CPU usage on the phone display. You can also set the phone to enter debug mode when USB connections are active.
About phone	View information about your phone, such as status, and legal information.

Other popular features

Some of the popular features that appear on the phone's Application menu are:

Downloads	Provides quick access to tabs containing a list of your current downloaded files.
File manager	Lets you view and manage files on both your phone storage and SD card. Organize and store data, music files, images, and more in your own personal file folders.
Search	Allows you to search something such as web, apps, contacts.
SIM toolkit	STK features are provided by your service provider. If your SIM card supports STK feature, you will see the STK menu. Different STK has different STK main menu. Please contact your service provider if the STK does not work. Note: The submenus of this feature depend on the operator and different operators may provide different services.

Accessing Password

The cell phone and SIM card use several accessing passwords. These passwords help to prevent the cell phone from being embezzled.

You can use the function options in the security settings of

settings menu to change accessing password (except for PUK and PUK2).

PIN Code

PIN code (Personal Identification Number) can prevent the SIM card from being embezzled. The PIN code is provided along with the SIM card. If the PIN code checking is activated, it is necessary to input the PIN code when the cell phone powers on every time.

If a wrong PIN code has been input for 3 times straight, it is needed to input the PUK code, then input a new PIN code and input it again for confirmation.

PIN2 Code

Some SIM cards may provide PIN2 code, while PIN2 code needs to be used in some functions like Call Cost. These functions can be used only if the SIM card supports them.

If a wrong PIN2 code has been input for 3 times straight, it is needed to input the PUK2 code, then input a new PIN2 code and input it again for confirmation.

PUK Code

PUK code (Personal Unlock Key) is used to change locked PIN code. PUK code is provided along with the SIM card. If not provided, please contact your local service provider for PUK code.

- If wrong PUK code has been input for 10 times straight, the SIM card can not be used any more. Please contact your service provider for a new SIM card.
- PUK code can not be changed. If the PUK code is lost, please contact your service provider.

PUK2 Code

PUK2 code is provided along with some SIM cards for changing locked PIN2 code.

- If wrong PUK2 code has been input for 10 times straight, the SIM card can not be used any more. Please contact your service provider for a new SIM card.
- The PUK2 code can not be changed. If it is lost, please contact your service provider.

Precautions

	Please carefully read and observe the terms below: Safe power on Do not use your mobile phone where it is forbidden to use or you might cause a disturbance or danger.
	Safe transportation first Please observe all related local laws and regulations. Do not use your mobile phone while driving. Safe transportation should be considered first when driving.
	Disturbance All mobile phone performances might be disturbed.
	Turn off when in the hospital Please follow related limitations. Please switch your mobile phone off when near a medical instrument.

	Turn off on an airplane Please follow related limitations. Do not use your mobile phone on an airplane.
	Turn off when at a gasoline station Do not use your mobile phone at a filling station or around fuels or chemicals.
	Turn off around exposure Area Please observe related limitations and do not use your mobile phone near an area where explosions can occur.
	Proper use As described in this manual, your mobile phone can be used only in the correct location. If possible, please do not touch the antenna area of your phone.
	Use qualified after sales service Only a qualified technician can install or repair your mobile phone. Please contact the authorized service center in case of phone failure.
	Accessories and batteries Only use the authorized accessories and batteries and do not connect to incompatible manufacturers or products.
	Waterproof Your mobile phone is not waterproof. Please keep it away from water.

	Backup Remember to make a backup or keep a written record of all important information saved in your mobile phone.
	Connect to other devices Please read the user manual of the device to get more detailed security instructions before connecting to other devices and do not connect to an incompatible product.
	SOS emergency calls Make sure your mobile phone is switched on and in a service area. In idle mode, input the SOS number, then press the Dial Key. Advise where you are and do not hang up without permission.

Frequently Asked Questions and Troubleshooting

Frequently Asked Questions	Cause and Solution
Fail to turn on	Press the power on key for over 1 second; Check if the battery is properly connected; Please remove and install it again, retry to turn it on; Check if battery is appropriately charged.
Fail to connect network	Weak signal. Please try and move to a location with strong signal and try connecting to the network again; Please ensure that you are not beyond the network coverage of service providers; Please ensure you have a valid SIM card; Please contact your network provider for

	further information.
Display information while turning on	Check if the SIM card is installed correctly; Handset lock password: If the handset lock is activated, you have to input handset password. Input PIN: Inputting PIN while turning on each time is activated, you have to input the PIN code. Input PUK code: When you've input wrong PIN code for 3 times will lock the SIM card. You need to input the PUK code provided by your network provider.
Poor quality of calling	Please check if the sound volume is tuned improperly ; In an area with poor receiving condition, for example: basement, the signal might be weak. Try searching a location with stronger signal reception and call again; While using the mobile phone in the peak period of communication, like commute time, you may be unable to call because of line congestion.
Standby duration shortened	The standby duration is relative to the system setting of network. While the mobile phone is in an area with poor signal strength and can not receive the signal, the handset will continuously search for a base station. This will significantly reduce battery charge. It is recommended that you turn off your mobile in area with no signal reception to save battery. Need replacing the battery. Please change a new battery.
SIM Card	Dirt on the metal surface of an SIM card: Use

Error	clean cloth to wipe the metal touch point on an SIM card; The SIM card is not installed: The SIM card is damaged. Please contact your network service provider.
Fail to dial out	Please check if you press the dial key after dialing; Please check if calling is forbidden because of defaulting; Please check if the SIM is valid; Please check if the call barring is set; Please check if the fixed dial function is set.
Callers can not contact you	Please check if the mobile phone is on and connected with the network; Please check if the Call barring or call divert is activated; Please check if the SIM card is valid.
Fail to charge	Poor contact: Please check if the plug is connected well; Please confirm if the environment temperature is within the range of 0°C ~40°C while charging; The battery or charger is damaged: You need to replace it.
Fail to set some functions	Wrong operation; The network provider does not support the function, or you have not applied for it.

Note: If the instruction above can not help you solve problems, please record Mobile phone model and serial number, Specific content of warranty, Clear statement of problems, Then contact your local dealer or the authorized service center in your area.

Safety Information and Notices

Using the Mobile Phone and Charger

Danger:

Only use authorized battery and charger. Using other brands may cause battery leakage, overheating, explosion or even fire.

Caution:

Keep the phone away from dust, water and damp areas. Dust, water or other liquids may cause overheating, electrical leakage, and/or phone failure.

The phone, battery, charger and AC adapter are not waterproof. Keep them away from rain and liquid.

Warning:

Do not bump, shake or tamper with the phone or charger. This may cause battery leakage, overheating, explosion or even fire. Do not place the battery, phone or charger near a microwave or high-voltage device. This may cause battery leakage, explosion, overheating or even fire; also prevent the phone and AC adapter from overheating, smoking or short circuiting.

Do not use the phone around volatile oil. This may cause fire, breakdown or damage.

To avoid any damage or breakdown, do not disassemble the phone, battery, charger or internal components by yourself.

Location:

The socket-outlet shall be installed near the equipment and shall be easily accessible.

Using the Mobile Phone

Warning:

Please confirm if the environment temperature is within the range of 0°C ~40°C while charging.

Do not use the phone while you are driving. Pull over and stop your automobile to dial or listen to a phone call.

Usage of mobile phones in aircrafts or hospitals is prohibited. Switch the phone off to prevent interference with electronic medical devices. Follow any rules or regulations in such places. Do not use the phone at a gas station, near fuel or near chemicals.

Do not use the phone near electronic medical devices such as hearing aids, pacemakers and auto-control devices such as fire detectors and automatic doors.

If you have to use your mobile phone near an electronic medical device such as a pacemaker, please contact your manufacturer or dealer for information about preventing interference.

Caution:

Electronic systems in automobiles such as anti-lock brakes, speed control, or fuel spraying systems, are usually not influenced by wireless devices. Manufacturers of these systems will tell you whether they are provided with good screening functions. If you suspect that an automobile failure is caused by a wireless wave, please contact your automobile dealer.

Avoid using your phone in crowded places.

Do not store your mobile phone near or with a credit card, disk or other magnetic materials. This may effect information stored on your phone.

Keep your phone away from pins. Pins can be absorbed by the phone's receiver magnet, which may cause harm.

If you intend not to use your mobile phone for a long period of time, please remove the battery from the phone. Leaving the battery inside the mobile phone for a long period of time may cause moisture to the battery, and it can damage the mobile

phone or the battery.

Battery& Chargers Safety:

- Do not place the battery in fire; follow local laws and ordinances in disposing used battery.
- Check the model number of the charger before using it to charge the mobile.
- Only use **original** battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger.
- Return waste and used batteries to the supplier or specified recovery site.

CAUTION

- There are risks of explosion if battery is replaced by a non-original one.
- Dispose of used batteries according to the instructions.

Note: The socket-outlet shall be installed near the equipment and shall be easily accessible.

Using the Battery

Danger:

- Do not dispose of the battery into a fire. Doing so may cause battery explosion or even fire.
- If you have difficulties installing the battery, do not force the installation. This may cause battery leakage, overheating, explosion or even fire.
- Keep metal objects away so they do not come in contact with the battery or its connectors as it may cause the battery to short circuit, overheat or explode.
- Do not weld the polarities of the battery directly together. This

may cause battery leakage, overheating, explosion or even fire. Battery liquid is severely harmful for your eyes. If battery liquid gets in your eyes, do not rub them. Instead, wash your eyes with water first and then go directly to a doctor for help.

- Do not use or store your phone in high temperature areas. This may cause battery leakage, overheating, explosion or even fire.

Warning:

- Replace the battery when the normal usage time begins to decrease or if you notice the battery is overheated or has changed shape or color.

- If battery liquid leaks onto your skin or clothes, immediately wash the affected parts with water.

- If the battery begins to leak or emits a strange odor, properly dispose of the battery according to local regulations. Do not throw it into a fire.

Caution:

Do not leave the product or its battery inside a vehicle. This may damage the product, overheat the battery, or pose a risk to the vehicle.

Warnings on Battery:

(a) Please use appointed battery in case of explosion risk.

(b) Please dispose of lifeless battery under guidance.

Using the Charger

Danger:

- Only use the charger that came with the phone. Using a different charger may cause the phone to breakdown or explode.

- If the charger short circuits, a fire may occur.

- Do not use a damaged, worn or broken charger. This may cause a fire.

- Clean dust away from the power socket to avoid the possibility of a fire.
- Do not store the charger near any liquids. If liquids spill onto the charger it may cause it to overheat or breakdown.
- If liquid does spill onto the charger, immediately unplug the power cable to prevent overheating, fire or another type of breakdown.
- Do not use the charger in places with high humidity like a bathroom. This may cause a fire or other breakdown.
- Do not touch the charger, power cable or socket with wet hands. This may cause an electric shock.

Requirements for Mobile Phone

- Avoid using your mobile phone in extremely high or low temperatures.
- It is recommended that you do not use your mobile phone near a telephone, TV set, radio or other radio frequency sensitive devices.

Requirements for the Battery

- When not in use, store the battery in a cool, well-ventilated place with sunshine.
- If you will not be using the mobile phone for an extended period of time, charge the battery on a regular basis to avoid battery breakdown.
- The phone battery wears out fast. If charging the battery does not improve its performance, it is time to replace the battery.
- Properly dispose of the battery according to local regulations. Do not throw it into a fire.

Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Requirements for the Charger and AC Adapter

Please confirm if the environment temperature is within the range of 0°C ~40°C while charging.

Cleaning and Maintenance

- The mobile phone, the battery and the charger are not waterproof.
- Do not use them in places with high humidity like a bathroom and also avoid spilling any liquids on them.
- Use a soft cloth to clean the mobile phone, the battery and the charger.
- Do not use alcohol, diluted liquid or benzene to clean the mobile phone.
- If dust gets in the sockets the phone can be damaged, short-circuit or even the lose the ability to be re-charged. Be sure to clean the socket regularly.

Infinix